


KOS-TYPE GEARED MOTOR PART LIST

- | | | |
|---|-------------------|-----|
| 1 | MOTOR ASS'Y----- | 1EA |
| 2 | GEAR CASE----- | 1EA |
| 3 | GEAR COVER----- | 1EA |
| 4 | OUTPUT SHAFT----- | 1EA |
| 5 | 2ND PINION----- | 1EA |
| 6 | 1ST GEAR----- | 1EA |
| 7 | MOTOR PINION----- | 1EA |



- | | | | |
|----|-------------|--------------|-----|
| 8 | BEARING | 6206DD--- | 1EA |
| 9 | BEARING | 6208DD-- | 1EA |
| 10 | BEARING | 6003ZZ-- | 1EA |
| 11 | BEARING | 6205ZZ- | 1EA |
| | BEARING | 6204ZZ- | 1EA |
| 12 | OIL-SEAL | 25*45*10- | 1EA |
| 13 | WRENCH-BOLT | M8*30- | 4EA |
| 14 | OIL-PLUGE | PF-1/8-- | 1EA |
| 15 | WRENCH-BOLT | M8*25- | 7EA |
| 16 | KEY | 6*6*15L----- | 1EA |